

# SWAMP Setup Guide

## XR-402



### Included Parts:

1. Left Panel (1)
2. Right Panel (1)
3. Support Bar (2) (bolts included)
4. Top Panel (3)
5. 4x Bolts (Top Panel to Left and Right Panel)
6. 4x Wheels

1. Attach the rear support bar (**Piece 2**), to both side panels (**Piece/s 1**)  
(*user may select which height level to attach support bar to*)  
Though do not tighten the bolts all the way up, leave them a tad loose.
2. **Sit** the top panel (**Piece 3**) **on top** of the side panels (**Piece/s 1**), lining up the holes on the side panels, to the screw thread holes on the top panel.
3. Use the **4x bolts** provided to attach through the side panel into the top panel.  
Start by turning the bolts by hand, and tighten all 4 bolts to only ~20% of full bolt length.  
(*ensure that each of the bolts is turning freely*)
4. Tighten the rear support bar (**Piece 2**) up fully.
5. Turn the unit over (so the top panel is on the ground), then continue to tighten the 4 bolts until the top panel (**Piece 3**) is completely tightened.
6. Attached the 4 wheels into the bottom of the side panels. Note that 2 wheels feature “locks”.  
Place them on one side of the front, and one side at the back, for maximum stability when locked.