

# Manual

JF-12 VOODOO OCTAVE

Thank you for purchasing our product, please read these instructions carefully before using it.

### I. Warning

- 1. Do not disassemble or repair this unit by yourself.
- 2. Do not use or store this unit in the following circumstances: high temperature, high humidity, dirty or strong shock places.
- 3. Do not drop off this unit or bump this unit off hard surface.
- 4. Do not use cleaning liquid or alcohol to clean this unit in case of damage.
- 5. Remove batteries if not using the unit for a long period of time.
- 6. Please dispose the used battery properly.

#### II. Battery replacement

- 1. Press the front of the battery cover and then slide back to remove the cover. Take out the flat batteries.
- 2.Put the battery into the battery compartment by placing the negative(-) pole of battery facing inside. Insert the front of cover and then press down and push to close.

## III. How to use

- A. To get the pedal ready by linking the connector wire.
- B. FUZZ—To adjust the degree of distortion of the tone.
- C. VOLUME——To adjust output level.
- E. MODE——1) Nomal; 2) MID Cut: This will filter the part of intermediate frequency.
- $\label{eq:F.OCTAVE} \textbf{F. OCTAVE} -- \textbf{To control the effect of ottava alta when being in FUZZ effect}.$
- G. LED——LED indicates power statement.
- H. Adapter——When you use an adapter, the battery inside will stop working automatically.

# IV. Specifications

Input Impedance:  $500 \text{K}\,\Omega$  Output Impedance:  $10 \text{K}\,\Omega$  Running Current: 4ma

Power: 6F22 9V Battery/ DC 9V adapter Dimension:120(L)×97(W)×55(H) mm

Weight:390g

SHEN ZHEN JOYO TECHNOLOGY CO.,LTD

www.joyoaudio.com