www.joyoaudio.com

A Safety instructions

Thank you for purchasing our products!

Important safety instructions



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of

important operating and maintenance (servicing) instructions in the literature accompanying the



This symbol is intended to alert the user--- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



User instructions: After you turn on the banTamP, the tube warms up for the first 20-30 seconds, the unstable sound during this period is normal.

Detailed safety instructions

- For your safety and let you be familiar with this product, please read all the safety and operation instructions
- Please keep this user manual for future use and maintenance.

Keep it away from children!

- Please follow all the safety instructions on the product or in the user manual. Use the attached power adapter only. If use other power adapter, it will damage the internal circuits or
- Please install this product according to manufacturer's instructions. Put it in places that have good ventilation and heat dissipation. Don't block any ventilation openings nor cover it with cloth and the like.
- Don't use it near water or damp areas, don't drop water or other liquid substance into this product; Don't use it near heat sources, such as heater, electrothermal oven, high power amplifier and more.
- Do not use alcohol or other cleaning fluids to clean this product, otherwise it will damage the surface, use a

Don't put hazardous chemicals on the product, inflammable and explosive substances such as alcohol,

- clean dry cloth when necessary. Don't damage the power cord or plug. Don't pull the power cord and other parts. Please unplug it if you need to move this product.
- Please turn off the power switch and unplug the AC power socket during thunderstorm, lightning or if it is not in use for a long time.
- Should any of the following occur, please switch it off and unplug it and contact your local distributor or have

-2-

- it repaired by qualified personnel. 1) Metal or other solid object or liquid falls into the cabinet, or gets caught in the rain.
- 2) The power cord or power plug were damaged, cable core are exposed or wire break. 3) The product is in smoke, peculiar smell or other abnormal condition.
- 4) The product falls on the ground or malfunctions.

Connection Panel instruction **8** Bluetooth connection ①Turn on the Bluetooth slide switch. 2 Its power indicator changes from red to blue. 3 Switch on the Bluetooth of your equipment, wait for it to locate ban TamP. Please note that the names located are according to different models you have bought, the 14 names are on the upper side of banTamP's input jack as 1011 12 13 shown in the picture, for example, "ZOMBIE" Front panel Rear panel 4 Click the related device and match. 1.Head's Model 10.Bluetooth Antenna MODERN HI-GAIN BRITISH HI-GAIN 11. Speaker Output: please connect with speaker ZOMBIE Cabinet impedance VIVO AMERICAN HARD ROCK BLUES OVERDRIVE impedance that is 8Ω or more than 8Ω ! Important matching ATOMIC BRITISH CLASSIC ROCK JACKMAN BRITISH CRUNCH notes: when connected with speaker impedance that Model vs Sound Characteristics is more than 8Ω , ban Tam P's power will be The matched speaker impedance is 2.Guitar Input. 8Ω , of course, 16Ω works too, but reduced. 3. Channel Switch: for choosing the channel. banTamP achieves maximum power 12.Power Interface: connects to DC 18V/2.5A 4.Bluetooth Switch: turn on/off banTamP's Bluetooth output only when speaker ·UOYO power adapter for power supply, make sure to use impedance is 8Ω . While with 16Ω , 5.Gain Knob: adjust the amp's distortion. the attached power adapter. banTamP' s power reduces. **6.Tone Knob:** adjust the amp's tone brightness. 13. Headphone Output: the amp becomes mute 7. Volume Knob: adjust the amp's volume. when it connects to headphones. 8. Power/Bluetooth indicator: turn on banTamP, the 14.FX LOOP: connects effect pedal input to indicator becomes red, then turn on Bluetooth switch, Please don't connect with speaker impedance that is less than 8Ω! banTamP's SEND jack, and connects effect pedal the indicator changes from red to blue. **9.Power Switch:** turn on/off banTamP. output to banTamP's RETURN jack. -3--4-

Specifications:

Power adapter: INPUT AC 110-240V 50/60Hz OUTPUT DC18V/2.5A Rated power: $20W/8\Omega$

Speaker Impedance: 8Ω **Dimension:**163mm×110mm×140mm

Weight:1200g

Package content: banTamP x1

Power adapter x1 User manual x1

JOYO TECHNOLOGY CO., LTD Address: 2/F, Lushi Industry Building, 28th District, Bao'an, Shenzhen, 518101 China.

www.joyoaudio.com Email:info@joyoaudio.com Tel: 0086-755-29765381

-5-

售后服务邮箱: ele@joyochina.cn 售后服务热线: 0755-29765393 68629762-2870 :真 91169762-8870:. 线热書辭內国 公司地址: 深圳市宝安28区陆氏大厦2楼 邮编:518133 WWW.JOYOCHINA.CN 后公别育麸埓宋阜市眦綵



Ix計即说 电频适配器x1 1x附至

:单帯薬団

30021:**重朴**


| 163mm×110mm×140mm|

A8: 法国伊卿

Ω8/W02:**率使宝藤**

車渡廷配器規格: INDUT AC 110-240V 50/60Hz OUTPUT DC18V/2.5A :獲箋戸由





-7-

。备级热发恳悼吝馨器大ガ率虎大,惊热身,胏戸麴,器热ኪ砹,器卧本用剪行此的源热迅靠弃要不●

;内协人倒卖人簖西汞的类之朴弥字其壶水将业禁,器协本用動行此的虚懈远水迅靠弃业禁●

孔。不要用物品覆盖着本机器; ●清色的主張中國主義 中國主義 不要要求 中國 "清聖它在島風風熱境的地方。清如風寒地器上所有的面面都,

。音鄵里卒迤朓本私患会銷佢,器酒适瓶申的替贼亏其用勤苦,器逼适溉申的拱戥朓本用勤銷只●

。阅查相要必掛以中即说用動本퍿資别善妥訂,品汽本养别昨用動此動式加更銷司以澂て代● 。몑说用動芒全安的育刑中许本稱野莊素屬畔對去青浦用動,品汽本用動穀燒此势更銷味全安的激下代●

明说全安的眼苇

-1-

Ţ/

的颛顼量阀重、栗功板转而的齑鹊屯界天又而器功有ガ紫颛顼量五移鲱山禁---白用告警号将刻



。

非明

说用

動

例 查请,即说养别麻沪操的要重育中护彻器办---互用踵毙来用号符刻,号观慰的育带中泺甬三贞等



。紐歆的击申知

> ! 廝受海郴兩受应时仍本, 劉奇申輔迤灾火聿发上阅长: 告警 ! 劉幹士人业寺由壽切要必! 盖那开秫秆自吹取, 更蛹土砌下长! 抖备用顶与用玩内办: 意至



:品气的的舞楽飘激傲葱