OCEAN VERB Manual

Thanks for purchasing our products, before operating this product, please read the enclosed operating instructions.

Operating Instructions



1.True BYPASS Footswitch
Press once: Switch between original sound and effect sound
Press twice: Switch between fixed mode and mode

2.LED indicator light
Green light: Nomal mode, can use knob to adjust parameters
Red light: Fixed mode,effector use the fixed parameter, knob cann't be use
Go out: Original sound

3.DECAY Knob
Adjust the decay.

4.TONE Knob
Adjust the tone color.

5.Mode Switch
Mode:ROOM/SPRING/SHIMMER.

6.MIX Knob
Adjusting the mixing ratio of original sound and effect sound.

7.Input Jack
1/4"mono audio jack,inputs the signal.

8.Output Jack
1/4"mono audio jack,outputs the signal.

9.DC IN Power Jack
DC 9V regulated AC adapter (Plug polarity is Positive on the barrel and negative in the center ⊕-⊖)

Product features

- DSP: 32 bit floating point, Sampling: 44.1kHz/ 24bit.
- 3 Models: ROOM/SPRING/SHIMMER

Specifications

- Input: 1/4″Monaural Jack (Impedance: 500K Ohms)
- Output: 1/4″Monaural Jack (Impedance: 10K Ohms)
- Power Supply: DC 9V (Plug polarity is Positive on the barrel and negative in the center ⊕-⊖)
- Working Current: 100mA
- Dimensions: 95(D)*45(W)*48(H)mm
- Weight: 273g(With box)